

FIG.1








the said the thing of the the transfer and the transfer a


				154	_
	DATA RECONSTRUCTING TABLE				
<u> </u>	_SPARE STORAGE UNIT SPARE 1		SPARE STORAGE UNIT SPARE 2		
2~	-STORAGE UNIT AT FAILURE #2		STORAGE UNIT AT FAILURE #4		
3~	POINT OF FAILURE		POINT OF FAILURE		
4~	FAILURE SECTOR OR ADDRESS	RECONSTRUC- TION JUDGEMENT FLAG	FAILURE SECTOR OR ADDRESS	RECONSTRUC- TION JUDGEMENT FLAG	5
	0000	1	0000	1	
	0001		000 I	1	
	0010	I	0010	0	
		<u>-</u>			
	FFFF	0	FFFF	0	

F16.4









and the state of t

